


Left Antenna Module, Avant


only "Chorus" through KW 21/04


- 1 - Connection for window antennas
- 1 - CLS
- 2 - FM/TS
- 3 - AM
- 2 - CLS connection (gray) to Comfort System Central Control Module -J393-
- 3 - TS connection (yellow) to Auxiliary Heater Radio Receiver -R64-
- 4 - AM/FM connection (white) to Radio -R-

All without TV antennas



- 1 - Connection for window antennas**
 - 1 - CLS
 - 2 - FM1/TS
 - 3 - AM
- 2 - CLS connection (gray) to Comfort System Central Control Module -J393-**
- 3 - TS connection (yellow) to Auxiliary Heater Radio Receiver -R64-**
- 4 - HF/IF connection (yellow) to/from Radio -R-/Navigation System with CD Drive Control Module -J401-/Radio/Navigation Display Control Module -J503-**
- 5 - FM3 connection (black) from Right Antenna Module -R109-**
- 6 - FM2 connection (brown) from rear window antenna**



**All with TV antennas****1 - Connection for window antennas**

1 - TV1/CLS

2 - FM1/TS

3 - AM

2 - CLS connection (gray) to Comfort System Central Control Module -J393-**3 - TS connection (yellow) to Auxiliary Heater Radio Receiver -R64-****4 - HF/IF connection (yellow) to/from Radio -R-/Navigation System with CD Drive Control Module -J401-/Radio/Navigation Display Control Module - J503-****5 - FM3 connection (black) from Right Antenna Module -R109-****6 - FM2/TV2 connection (brown) from rear window antenna****7 - TV1/TV2 connection (green) to Navigation/TV Tuner -J415-**

Only radio generation II+**1 - Connection for window antennas**

1 - CLS

2 - FM1/TS

3 - AM

2 - CLS connection (gray) to Comfort System Central Control Module -J393-**3 - TS connection (yellow) to Auxiliary Heater Radio Receiver -R64 -****4 - AM/FM1 connection (yellow) to Radio -R-****5 - FM2 connection (yellow) to Radio -R-****6 - FM2 connection (brown) from rear window antenna**